

MR8534/MR8570/MR8590



SAFETY SENSOR FOR AUTOMATIC REVOLVING DOORS

User's Guide for product version 0500 and higher

See product label for serial number


CAME



ENGLISH

DESCRIPTION


Is a safety sensor for automatic revolving doors based on active infrared technology. It secures the area in front of the moving door leaf. To do so, modules must be installed on the top rail of the door leaf.




TECHNICAL SPECIFICATIONS

Technology:	active infrared with background suppression
Emission field:	400 mm (W) x 70 mm (D) (at 2 m mounting height; 4 spots active)
Mounting height:	1.3 m to 3.5 m
Reaction time:	64 ms (typ)
Max. presence time:	1 minute
Supply voltage:	12 V - 24 V AC +/-10% ; 12 V - 30 V DC -5%/+10% (to be operated from SELV compatible power supplies only)
Max current consumption:	95 mA @ 24 V AC/ 70 mA @ 24 V DC; 170 mA @ 12 V AC/ 130 mA @ 12 V DC (MASTER) 85 mA @ 24 V AC/ 60 mA @ 24 V DC; 180 mA @ 12 V AC/ 113 mA @ 12 V DC (other modules)
Output:	2 relays (free of potential contact)
Max. contact voltage	42 V AC/DC
Max. contact current	1 A (resistive)
Max. switching power	30 W (DC) / 42 VA (AC)
Input:	1 optocoupler (free of potential contact)
Max. contact voltage:	30 V
Voltage threshold:	high: >10 V DC; low: <1 V DC
Max. number of modules:	4 (up to 6 if 24 V DC)
Reflectivity:	min. 5% at IR-wavelength of 850 nm
Degree of protection:	IP54
Temperature range:	-25 °C to +55 °C; 0-95% relative humidity, non condensing
Expected lifetime:	20 years
Conformity:	DIN 18650-1: ch. 5.7.4; EN 16005 ch. 4.6.8; EN 12978; IEC/EN 61508 (SIL2) EN ISO 13849-1 Performance Level «c» CAT. 2 (under the condition that the door control system monitors the sensor at least once per door cycle)

1 MOUNTING THE PROFILE




Mount the profiles as close as possible to the closing edge. Leave 2 cm for the black end caps. Take the position of the white clips into account before drilling and fastening the screws.




To loosen the modules, please use a screwdriver.

2 POSITIONING THE MODULES



Place the transmitter (TX) next to the door edges that needs to be protected.


Position the angle adjustment clip next to the transmitter.




If necessary, turn the module and reposition the clips as indicated.

1. Detach the clips
2. Turn them by 180°
3. Reattach


3 WIRING



The module connected to the door controller becomes the **MASTER**.




Plug the SLAVE CABLE between the modules in one of the two placements.



* Output status when sensor is operational
 ** For compliance with EN 16005 and DIN 18650, connection to door controller test output is required.
 *** If door controller is not tested: connect BLUE to 0 V and RED to +12 V - 30 V DC.

4 SETTINGS



ON

OFF

MOUNTING
SIDE

RELAY 1
STOP

RELAY 2
REOPENING

FREQUENCY

FREQ A

FREQ B

BACKGROUND

ON

OFF

UNCOVERED
ZONE

HIGH*

LOW

FACTORY VALUE

LED during detection:
R1 > RED
R2 > GREEN

Set different
frequencies on
modules close to
each other.

Not enough background
reflectivity: switch to OFF

* Recommended for most applications.
Mounting height > 2.7 m: set to LOW for
EN 16005 and DIN 18650-conformity.



ORANGE



GREEN



OFF



After changing a DIP-switch, the orange LED flashes.

A LONG push on the push button of the **MASTER**
confirms the settings of ALL MODULES.

Afterwards, a number of green flashes (x) indicates
the number of connected modules.

5 CALIBRATION



A SHORT push on the button of the **MASTER** launches a
calibration on ALL MODULES.

Do not stand in the detection field!



RED-GREEN



OFF

When the LED is off on all modules, the detection zone is OK.



GREEN

The detection zone is too short:
turn the screw clockwise.



RED

The detection zone is too long:
turn the screw anticlockwise.



ORANGE


Step out of the detection field.

If necessary, change angle or switch off background (DIP 3 = OFF).



ORANGE

Launch a new calibration.




The flashing speed of
the LED increases when
approaching the optimal
position.

6 DOOR SAFETY CHECK

IMPORTANT: Test the good
functioning of the installation
before leaving the premises.

If necessary, position spots
closer to or away from the door
and **relaunch a calibration**.



LED-SIGNALS

 	The RED or GREEN LED is ON sporadically or permanently.	Bad calibration	1 Launch a calibration.
		Bad adjustment of the uncovered zone.	1 Check if the DIP-switch 4 is in correct position. 2 Launch a calibration.
		The sensor is disturbed by lamps or another sensor.	1 Select a different frequency for each module (DIP 2). 2 Launch a calibration.
	The sensor does not react, but a calibration can be launched.	The monitoring is activated, but the test input is not powered.	1 Check wiring. - Door control with test: Connect RED and BLUE wires to test output. - Door control without test: Connect BLUE to 0 V and RED to +12 V - 30 V DC.
	The ORANGE LED is on permanently.	The sensor encounters a memory problem.	1 Send the sensor back for a technical check-up.
	The ORANGE LED flashes quickly.	DIP-switch setting awaiting confirmation.	1 Confirm the DIP-switch setting: long push on the push button.
	The ORANGE LED flashes 1 x every 3 seconds.	The sensor signals an internal fault.	1 Cut and restore power supply. 2 If orange LED flashes again, replace sensor.
	The ORANGE LED flashes 2 x every 3 seconds.	Power supply is out of limit.	1 Check power supply (tension, capacity). 2 Reduce the cable length or change cable.
	The ORANGE LED flashes 3 x every 3 seconds.	Communication error between modules.	1 Check wiring between modules. 2 Launch a module count: long push on push button of MASTER.
	The ORANGE LED flashes 4 x every 3 seconds.	The sensor receives not enough IR-energy.	1 Launch a new calibration and step out of the detection field. 2 Change angle of spots. 3 Switch off background (DIP 3: OFF).
	The ORANGE LED flashes 5 x every 3 seconds.	Calibration error	1 Check mounting height. 2 Change position of calibration screw. 3 Launch a new calibration. 4 Switch off background (DIP3: OFF)

- The device cannot be used for purposes other than its intended use. All other uses cannot be guaranteed by the manufacturer of the sensor.
- The manufacturer of the door system is responsible for carrying out a risk assessment and installing the sensor and the door system in compliance with applicable national and international regulations and standards on door safety.
- The manufacturer of the sensor cannot be held responsible for incorrect installations or inappropriate adjustments of the sensor.
- Only trained and qualified personnel may install and setup the sensor.
- The warranty is invalid if unauthorized repairs are made or attempted by unauthorized personnel.



Came S.p.A. - Via Martiri Della Libertà 15 - IT-31030 DOSSON DI CASIER (TV)
 TEL (+39) 0422 4940 - FAX (+39) 0422 4941 - info@came.com - www.came.com
 CAME hereby declares that MR8534/MR8570/MR8590 is in compliance with European directives 2014/30/EU (EMC), 2006/42/EC (Machinery) and 2011/65/EU (RoHS).
 Original upon request.



This product should be disposed of separately from unsorted municipal waste.



BUY TO SELL PRODUCT
 ПОРТАЛ ПО БЕЗОПАСНОСТИ

CAME 